

INSTALLATION MANUAL

airHome  
400

SPLIT TYPE AIR CONDITIONER

OUTDOOR UNIT  
RAC-DJ12WHAA



EN INSTRUCTION MANUAL

FOR SERVICE PERSONNEL ONLY

- Carefully read through the procedures of proper installation before starting installation work.
- The sales agent should inform customers regarding the correct operation of installation.

Tools Needed For Installation Work

- ⊕ mark is tool exclusive use for R32
- ⊕ Screwdriver
- ⊕ Measuring Tape
- ⊕ Knife
- ⊕ Saw
- ⊕ Pipe Cutter
- ⊕ Hexagonal Wrench Key (⊕) 5/32"(4mm)
- ⊕ Power Drill (⊕ 2-18/32" (65mm) ~ ⊕ 3-5/32" (80mm))
- ⊕ Vacuum Pump
- ⊕ Pliers or Wrench
- ⊕ Torque Wrench
- ⊕ Vacuum Pump Adaptor
- ⊕ Flare Tool
- ⊕ Gas Leakage Detector
- ⊕ Manifold Valve
- ⊕ Charge Hose
- ⊕ Reamer
- ⊕ File

Refrigerant pipe size (outer diameter): Narrow pipe, Liquid (ø8/32"(6.35mm); Wide pipe, Gas (ø16/32"(12.70mm)/ø20/32"(15.88mm))

SAFETY PRECAUTION

Read the safety precautions carefully before operating the unit.



This appliance is filled with R32.

- The contents of this section are vital to ensure safety. Please pay special attention to the following sign.
- WARNING** ..... Incorrect methods of installation may cause death or serious injury.
- CAUTION** ..... Improper installation may result in serious consequence.

Make sure to connect earth line. This sign in the figures indicates prohibition. Be sure that the unit operates in proper condition after installation. Explain to customer the proper operation and maintenance of the unit as described in the user's guide. Ask a customer to keep this installation manual together with the instruction manual.

Access the full version of the User Installation Manual by scanning the code.



Table 1: Minimum Floor area of the room A<sub>min</sub> (m<sup>2</sup>)

Model	Max. Pipe ft(m)	Chargeless up to ft(m)	Additional R32 oz/ft(g/m)	The maximum refrigerant charge (mmax)
RAC-DJ12WHAA	82-1/32ft (25m)	49-7/32ft (15m)	0.11oz/ft (10g/m)	31.75oz (900g)

	This appliance is filled with R32.		This symbol shows that a service personnel should be handling this equipment with reference to the Installation Manual.
	This symbol shows that the Operation Instructions should be read carefully.		This symbol shows that there is information included in the Operation Manual and/or Installation Manual




Figure 1

CAUTION

- A circuit breaker or fuse must be installed. Without a circuit breaker or fuse the danger of electric shock exists. The external switch shall be incorporated to completely disconnect from power supply. It should disconnect all poles, and a contact separation of at least 4/32" (3mm) must be present.
- Do not install the unit near a location where there is flammable gas. The outdoor unit may catch fire if flammable gas leaks around it.
- Do not install the indoor unit in a machine shop, kitchen and laundry rooms when vapor from oil or its mist flows to the indoor unit. The oil will deposit on the heat exchanger, thereby reducing the indoor unit performance and may deform and in the worst case, break the plastic parts of the indoor unit.
- Please ensure smooth flow of water when installing the drain hose.
- Piping shall be suitable supported with a maximum spacing of 3-9/32ft (1m) between the supports.
- Selecting the installation location: Suitable location that will reduce the impact from rain and direct sun that may affect the unit performance. Besides that, ventilation must be good and clear of obstruction.
- The air blown out of the unit should not point directly to animals or plants.
- The clearances of the unit from top, left, right and front are specified in figure below. At least three of the above sides must be open air.
- Be sure that the hot air blown out of the unit and noise do not disturb the neighbourhood.
- Do not install at a location where there is flammable gas, steam, oil and smoke.
- The location must be convenient for water drainage.
- Place the outdoor unit and its connection wire at least 3-9/32ft (1m) away from the antenna or signal line of television, radio or telephone. This is to avoid noise interference.
- Do not install outdoor unit facing strong wind direction. It may damage the fan motor.
- Do not install the outdoor unit in a place where small animals may build their nests. If small animal goes inside the unit and touches the electrical parts, failure of the unit, smoke or fire may be caused. Request your customer to keep the surrounding of the unit is clean.
- Safely dispose all packing and transportation materials in accordance with federal/state/local laws or ordinances. Packing materials such as nails and other metal or wood parts, including plastic packing materials used for transportation may cause injuries or death by suffocation.
- The maximum number of pieces of equipment permitted to be stored together will be determined by local regulations. Storage package protection should be constructed in such a way that mechanical damage to the equipment inside the package will not cause a leak of the REFRIGERANT CHARGE.

WARNING

- Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer. Any unfit method or using incompatible material may cause product damage, burst and serious injury.
- The appliance/pipe-work shall be stored in a well ventilated room with indoor floor area larger than A<sub>min</sub> [refer to Table 1] and without any continuously operating ignition source. Keep away from open flames, any operating gas appliances or any operating electric heater. Else, it may explode and cause injury or death.
- The appliance/pipe-work shall be installed, and/or operated in a room with floor area larger than A<sub>min</sub> [refer to Table 1] and keep away from ignition sources, such as heat/spark/open flame or hazardous areas such as gas appliances, gas cooking, reticulated gas supply systems or electric cooking appliances, etc.
- Do not pierce or burn as the appliance/pipe-work is pressurized. Do not expose the appliance/pipe-work to heat, flame, sparks, or other sources of ignition. Else, it may explode and cause injury or death.

The Choice of Mounting Site (Please note the following matters and obtain permission from customer before installation).

WARNING

- The Outdoor unit must be mounted at a location which can support heavy weight. Otherwise, noise and vibration will increase.

CAUTION

- Do not expose the unit under direct sunshine or rain. Besides, ventilation must be good and clear of obstruction.
- The air blown out of the unit should not point directly to animals or plants.
- The clearances of the unit from top, left, right and front are specified in Figure 1. At least 3 of the above sides must be open air.
- Be sure that the hot air blown out of the unit and noise do not disturb the neighbourhood.
- Do not install at a location where there is flammable gas, steam, oil and smoke.
- The location must be convenient for water drainage.
- Place the Outdoor unit and its connecting cord at least 3.28ft(1m) away from the antenna or signal line of television, radio or telephone. This is to avoid noise interference.
- Do not install outdoor unit facing strong wind direction. It may damage the fan motor.
- Do not install the outdoor unit in a place where small animals may build their nests. If small animal goes inside the unit and touches the electrical parts, failure of the unit, smoke or fire may be caused. Request your customer to keep the surrounding of the unit is clean.

Names of Outdoor Components

No.	Item	Qty
①	Bush	3
②	Drain Pipe	1
③	Bush	1





Figure showing the Installation of Outdoor Unit.

CAUTION

- This unit is chargeless up 49-7/32ft (15m) pipe length.
- Installation of pipe length less than minimum pipe length requirement 9-27/32ft (3m) may generate an abnormal sound.


OUTDOOR UNIT

- Please mount the outdoor unit on stable ground to prevent vibration and increase of noise level.
- Decide the location for piping after sorting out the different types of pipe available.
- Open the side plate by unscrewing the screws as shown beside.



CONDENSED WATER DISPOSAL OF OUTDOOR UNIT

- There are holes on the base of Outdoor unit for condensed water to exhaust.
- In order to flow condensed water to the drain, the unit is installed on a stand or a block so that the unit is 3-15/16"(100mm) above the ground as shown figure. Join the drain pipe to one hole.
- At first insert one portion of the hook to the base (Portion A), then pull the drain pipe in the direction shown by the arrow while inserting the hook into the base. After installation, check whether the drain pipe cling to the base firmly.



When Using and Installing in Cold Areas

When the air conditioner is used in low temperature and in snowy conditions, water from the heat exchanger may freeze on the base surface to cause poor drainage. When using the air conditioner in such areas, do not install the bushings. Keep a minimum of 9-27/32" (250mm) between the drain hole and the ground. When using the drain pipe, consult your sales agent.

※ For more details, refer to the installation Manual for Cold Areas.

WARNING

- Use the two spanners on the service valve nuts to tighten and loosen so that the service valve will not deform. Gas leak from the crushed part, stagnation, touching fire, rarely cause ignition.



PURGING OF REFRIGERANT IS PROHIBITED

Purging of refrigerant will cause the unit to be lacked of refrigerant which may affect the capacity performance and lead to severe dew formation causing problem such as dew water drop or splashing from the unit.

When connecting pipes. If you tighten the flare nut by excess torque, the service valve on the small pipe side may be broken. The flare nut on the small pipe side should be torqued to 122 - 165lbf.in (140 - 190kgf.cm).

WARNING

**BURST HAZARD**  
Do not allow air, etc. to get into refrigerant cycle (piping)

**RISK OF EXPLOSION**  
Compressor must be stopped before removing refrigerant pipes. All service valve must be fully closed after pumping down operation.

### 1 Preparation of Pipe

- Use a pipe cutter to cut the copper pipe.



#### CAUTION

- Jagged edge will cause leakage.
- Point the side to be trimmed downwards during trimming to prevent copper chips from entering the pipe.
- Before flaring, please put on the flare nut.




- Recommend to use R32 flaring tool.

Outer diameter in(mm)	Thickness in(mm)	A in(mm)		
		Flare tool for R32 Clutch type	Conventional flare tool	
1/4"(6.35mm)	1/32(0.8)	0~1/64(0.0~0.5)	3/64~1/16(1.0~1.5)	1/16~5/64(1.5~2.0)
3/8"(9.52mm)	1/32(0.8)	0~1/64(0.0~0.5)	3/64~1/16(1.0~1.5)	1/16~5/64(1.5~2.0)
1/2"(12.70mm)	1/32(0.8)	0~1/64(0.0~0.5)	3/64~1/16(1.0~1.5)	1/16~3/32(1.5~2.5)
5/8"(15.88mm)	3/64(1.0)	0~1/64(0.0~0.5)	3/64~1/16(1.0~1.5)	1/16~3/32(1.5~2.5)

### 2 Pipe Connection

- CAUTION** In case of removing flare nut of an Indoor unit, first remove a nut of small diameter side, or a seal cap of big diameter side will fly out. Prevent water from entering into the piping when working.


		Outer dia. of pipe in(mm)	Torque N.m (lbf.ft)
Flare nut	Small dia. side	1/4"(6.35mm)	13.7-18.6 N.m (10.08-13.68 lbf.ft)
	Large dia. side	3/8"(9.52mm)	34.3-44.1 N.m (25.20-32.40 lbf.ft)
		1/2"(12.7mm)	44.1-53.9 N.m (32.40-39.60 lbf.ft)
Valve head cap	Small dia. side	1/4"(6.35mm)	19.6-24.5 N.m (14.40-18.00 lbf.ft)
		3/8"(9.52mm)	19.6-24.5 N.m (14.40-18.00 lbf.ft)
	Large dia. side	1/2"(12.7mm)	29.4-34.3 N.m (21.60-25.20 lbf.ft)
		5/8"(15.88mm)	29.0-31.0 N.m (21.31-22.75 lbf.ft)
	Valve core cap		12.3-15.7 N.m (8.75-11.52 lbf.ft)




### 3 Removal Of Air From The Pipe And Gas Leakage Inspection

#### Procedures of using Vacuum Pump for Air Removal

- As shown in right figure, remove the cap of valve core. Then, connect the charge hose. Remove the cap of valve head. Connect the vacuum pump adapter to the vacuum pump and connect the charge hose to the adapter.
- Fully tighten the "Hi" knob of the manifold valve and completely unscrew the "Lo" knob. Run the vacuum pump for about 10~15 minutes, then completely tighten the "Lo" knob and switch off the vacuum pump.
- Remove the charge hose and tighten the cap of valve core. Check the cap's periphery if there is any gas leakage.
- Completely unscrew the spindle of the service valve (at 2 places) in anti-clockwise direction to allow the flow of refrigerant (using Hexagonal Wrench key).
- Re-cap the service valve and tighten using wrench. Check the cap's periphery if there is any gas leakage. The task is then completed.



When the meter reaches - 101KPa (-76cmHg) during pumping, fully tighten the shuttle.




#### CAUTION

- Prevent moisture from entering pipe connection.
- Refrigerating machine oil not be applied to the outside of the flare.
- When refrigerating machine oil is applied to the outside of the flare, excessive tightening of the flare nut, cracking of the flare nut, destruction of the flare and gas leakage may occur.
- When using the control valve, do not use deteriorated packing. And, do not overtighten the steering wheel.
- Gas leakage from the service valve part, stagnation, touching fire, rarely cause ignition.

#### Gas Leakage Inspection

Please use gas leakage detector to check if leakage occurs at the connection of Flare nut as shown on the right.


If gas leakage occurs, further tighten the connection to stop leakage. (Be sure to use R32 detector)



#### WARNING THIS APPLIANCE MUST BE EARTHED.


#### Procedures of Wiring

In case that power is supplied from Indoor unit



#### Detail of Cutting the Connecting Cord

Outdoor Unit



#### Wiring of The Outdoor Unit


- Please remove the side plate for wire connection.

#### WARNING

- If you cannot close the side cover due to the connecting cord, please tidy up the wiring for spacing at front panel.
- Be sure that the hooks of the side cover is properly fixed to avoid water penetration. Otherwise water leakage may occur and this causes short circuit or faults.
- The connecting cord should not touch to service valve and pipes to avoid possibilities of burn. (It becomes high temperature in heating operation.)

#### Checking for the electric source and the voltage range

- Before installation, the power source must be checked and necessary wiring work must be completed. To make the wiring capacity proper, use the wire gauge list below for the wiring from house distribution fuse box to the outdoor unit in consideration of the locked rotor current.
  - Investigate the power supply capacity and other electrical conditions at the installing location.
- Depending on the model of room air conditioner to be installed, request the customer to make arrangements for the necessary electrical work etc.
- The electrical work includes the wiring work up the outdoor unit. In localities where electrical conditions are poor, use of a voltage regulation is recommended.
- Install outdoor for the room air conditioner within the reaching range of the line cord.



For (Power cord - L, N, ground)	For (Connecting cord - 1, 2, 3, ground)	
Wire cross-section	Wire length	Wire cross-section
AWG#14 (2.5 mm <sup>2</sup> )	up to 82-1/64ft(25m)	AWG#14 (2.5mm <sup>2</sup> )

#### CAUTION


- Note:
- The supply cord of appliances for outdoor use shall be between 4-59/64ft & 9-27/32ft (1.5m & 3m) long and shall be either an EXTRA HARD USAGE or a HARD USAGE CORD.

#### IMPORTANT

Maximum Overcurrent Protection Fuse
15A

#### WARNING


- Leave some space in the connecting cord for maintenance purpose and be sure to secure it with the cord band.
- Secure the connecting cord along the coated part of the wire using the cord band. Do not exert pressure on the wire as this may cause overheating or fire.



### 1 Insulation And Maintenance Of Pipe Connection

- The connected terminals should be completely sealed with heat insulator and then tied up with rubber strap.
- Please tie the pipe and power line together with vinyl tape as shown in the figure showing the installation of Indoor and Outdoor units. Then fix their position with holders.
- To enhance the heat insulation and to prevent water condensation, please cover the outdoor part of the drain hose and pipe with insulation pipe.
- Completely seal any gap with putty.

Insulation material for pipe connection



### 2 Power Source And Operation Test

#### Power Source

#### WARNING

- Please use a new socket. Accident may occur due to the use of old socket because of poor contact.
- Please plug in and then remove the plug for 2 - 3 times. This is to ensure that the plug is completely plugged into the socket.
- Keep additional length for the power cord and do not render the plug under external force as this may cause poor contact.
- Do not fix the power cord with U-shape nail.

#### Operation Test

- Please be sure to measure the supply voltage before operation test.
- Please ensure that the air conditioner is in normal operating condition during the operation test.
  - Operate with Cool Mode(in summer) or Heat Mode(in winter).
  - Press Temperature Button on the remote controller to set the desired temperature to 60°F (16.0°C) for Cool Mode or 90°F (32.0°C) for Heating Mode. Set the desired fan speed to " (High).
  - Operate the air conditioner for 20 minutes at least and make sure that the air from the air conditioner is cool or warm.

- Press the ON/Off button on the remote controller to make sure that the air conditioner stops running.

- If the indication lamps of the indoor unit blink with sounding the buzzer during the operation test, perform a check following the procedures below.

Indication lamps blinking mode	What do check
All indication lamps blink three times repeatedly.	Make sure that the spindles of both service valves are open. (Outdoor fan might operate for near 15 minutes after the operation stop for the protection. For the reoperation at that case, do it after outdoor fan will stop.)

- Before the check and the reoperation, reset the power supply by turning off and on the circuit breaker only after
  - waiting for at least 5 minutes; or
  - pressing the Temporary Switch Button only once while the power is OFF.

#### California Proposition 65

#### WARNING

Proposition 65: This product contains chemicals known to the state of California to cause cancer, birth defects, and other reproductive harm. For more information, go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

#### CAUTION

- Don't operate for over 5 minutes with the situation that the spindle of the service valve is closed. This will cause the defect.
- Don't operate by Cool Mode or Dry Mode with the door and windows opened, (the room humidity is always above 80%) for a long period of time. Water will condense and drip down occasionally. This will wet your furniture.
- Explain to your customer the proper operation procedures as described in the user's manual.
- If the indoor unit won't operate, check the cable for correct connection.
- Turn on the lamp in the room where the indoor unit is installed and check the remote controller for normal operation.